






ANATOMI KAMERA




TOUS DROITS RÉSERVÉS
PROPRIÉTÉ EXCLUSIVE
DE NIKON
REPRODUCTION
RIGOREUSEMENT INTERDITE




35 mm "full frame"
36 × 24 mm
864 mm²




APS-H (Canon)
28.7 × 19 mm
548 mm²




APS-C (Nikon, Sony,
Pentax, Fuji etc.)
~23.6 × 15.7 mm
~370 mm²




APS-C (Canon)
22.2 × 14.8 mm
329 mm²



Foveon (Sigma)
20.7 × 13.8 mm
286 mm²



Four Thirds System
(Olympus, Panasonic)
17.3 × 13 mm
225 mm²



1" (Nikon, Sony)
13.2 × 8.8 mm
116 mm²



2/3" (Fuji, Nokia)
8.6 × 6.6 mm
58.1 mm²



1/1.7"
7.6 × 5.7 mm
43 mm²



1/2.5"
5.76 × 4.29 mm
25 mm²

Bagian Kamera (body)




1. Tombol On/Off
2. Lubang tali gantungan
3. Shutter release
4. Auto focus lamp/self timer
5. Lens Mount
6. Built in Flash
7. Mirror
8. Flash pop up button
9. Build in microphone
16. Tombol pemuka lensa
17. Tombol AF



- 23. Tong Sampah
- 25. Viewfinder
- 26. Viewfinder eyepiece
- 27. Diopter adjustment control
- 28. Metering selector
- 31. Main command dial
- 32. Multi selector
- 33. Memory card slot
- 37. Live view button
- 41. Monitor
- 42. OK button
- 43. ISO button
- 44. WB/ lock button
- 45. Menu
- 46. Play button




- 48. Pengaturan Mode
- 49. Control panel
- 54. Accessory shoe



- 58. Battery-chamber cover
- 60. Lubang tripod



- 61. Connector cover
- 62. USB connector
- 63. DC in
- 64. Video Out
- 65. remote



Bukaan Rana



ISO





TerimaKasih