

KODE BCD

BCD 4 Bit	Decimal
0000	0
0001	1
0010	2
0011	3
0100	4
0101	5
0110	6
0111	7
1000	8
1001	9

KODE SBCDIC

BA8421	KARAK TER	BA8421	KARAK TER	BA8421	KARAK TER	BA8421	KARAK TER
001010	0	110001	A	100010	K	010100	U
000001	1	110010	B	100011	L	010101	V
000010	2	110011	C	100100	M	010110	W
000011	3	110100	D	100101	N	010111	X
000100	4	110101	E	100110	O	011000	Y
000101	5	110110	F	100111	P	011001	Z
000110	6	110111	G	101000	Q		
000111	7	111000	H	101001	R		
001000	8	111001	I	010010	S		
001001	9	100001	J	010011	T		